

# Quick Reference

## Optional Functions incl. AudioLine



### STUDENT 1 TO ALL

Student 1 is selected as transmitter, the instructor and all other students are selected as receivers.



### INSTRUCTOR TO STUDENT 3

The instructor is selected as transmitter and student 3 is selected as receiver. Other students may be added to this selection also as receivers.



### VIDEO SCANNER

Hold down the ALT FUNCT key while pressing the ALL key. The instructor receives all students' screens sequentially for about 3 seconds. To increase the time delay hold the ALT FUNCT key pressed down.



### LOCK ALL

Hold down the ALT FUNCT while pressing the KEYB. LOCK key. There is no video transmission required. The KEYB. LOCK key is flashing to indicate the all mode.



### REMOTE CONTROL ALL

Hold down the ALT FUNCT key while pressing the REMOTE key. One student's screen must be transmitted to the instructor. The remote key is flashing. Note: All systems must run in the same application, in the same mode!



### SCREEN ACCESS

This will allow any student, by pressing the HELP button, to receive the instructor's screen for guidance. Any number of students can access this function at the same time.



### AUDIO DIALOGUE

The instructor receives any student's screen and he can hear the student. Any number of student can access this function at the same time.



### INSTRUCTOR TO ALL

All students can hear the instructor. There is no video transmission required. INTERCOM is not turned off by video off.



### BEAMER NOTEBOOK

Displays the notebook screen directly onto the beamer, independent of other settings (e.g. INSTRUCTOR to ALL). Both settings are working simultaneously. VIDEO OFF will NOT turn off the Beamer-Notebook function. To turn it off, hit the key again or replace it by the function BEAMER INSTRUCTOR.



### BEAMER INSTRUCTOR

Displays the instructor's screen directly onto the beamer, independent of other settings (e.g. STUDENT to INSTRUCTOR). Both settings are working simultaneously. VIDEO OFF will NOT turn off the BEAMER-INSTRUCTOR function. To turn it off, hit the key again or replace it by the function BEAMER NOTEBOOK.

*Advanced System*

Manufacturer:

**EBS Euchner Büro- und Schulsysteme GmbH**  
Ernst-Leitz-Straße 3 · D - 63150 Heusenstamm (Germany)  
Tel.: +49 61 04-33 13 · Fax: +49 61 04-17 83  
E-Mail: [info@ebs-euchner.com](mailto:info@ebs-euchner.com) · [www.ebs-euchner.com](http://www.ebs-euchner.com)