


# Help Button & Screen Access




## videodidact<sup>®</sup> Select



### Help Button for Students

The call for help offers every student the possibility of getting in touch from his desk with the instructor. The instructor is being notified on the videodidact © keyboard by an acoustic and by a visual signal if a student pushes the Help Button. The instructor can give support by using the video transmission and the remote control. All help reports are being collected and shown until the instructor either deletes such by **VIDEO OFF** or until the instructor presses the respective student button.



### Instructor/Screen Access

With the **SCREEN ACCESS** button the instructor can release his screen for viewing to all individual students. Each student can then retrieve the teacher's screen by pressing the Help Button. By pressing the button once more the student has his own picture returned. If in **SCREEN ACCESS** mode there is no acoustic signal.

If a student is being selected as a transmitter on the videodidact © keyboard the corresponding picture of the selected student is callable instead of the instructor's screen (supply teacher function).

Keyboard and mouse of a desk get closed at reception of a from outside picture automatically if the hardware remote control is installed.

Manufacturer:

**EBS Euchner Büro- und Schulsysteme GmbH**  
Ernst-Leitz-Straße 3 · 63150 Heusenstamm · Germany  
Tel.: +49-61 04-33 13 · Fax: +49-61 04-17 83  
E-Mail: [info@ebs-euchner.com](mailto:info@ebs-euchner.com) · [www.ebs-euchner.com](http://www.ebs-euchner.com)