


# Help Function (optional)



## Call for help by the students

The call for help offers every student the possibility of calling the instructor.

By pushing the Help Button at the respective student place an acoustic and a visual signal is notified on the instructor's videodidact® keyboard. The instructor can support the students with the video transmission and the remote control. All help reports are being collected and shown until the instructor deletes them by pushing **VIDEO OFF** or by pushing any other button.



Manufacturer:

**EBS Euchner Büro- und Schulsysteme GmbH**  
Ernst-Leitz-Straße 3 · D - 63150 Heusenstamm (Germany)  
Tel.: +49 61 04-33 13 · Fax: +49 61 04-17 83  
E-Mail: [info@ebs-euchner.com](mailto:info@ebs-euchner.com) · [www.ebs-euchner.com](http://www.ebs-euchner.com)